

INTRODUCTION

This Bluetooth wireless speaker system applies the latest BT 2.1 wireless technology platform that enables you to enjoy music, video and cell phone handsfree calling everywhere you want.

A. PACKAGING

1. Bluetooth stereo speaker
2. USB to Micro USB charging cable
3. 3.5mm to 3.5mm audio cable

B. FEATURES

1. Bluetooth 2.1 Platform
2. A2DP profile
3. Handsfree telephone calling
4. Stereo music
5. Battery status checking
6. Operating distance up to 10 meters / 33 feet (open area)
7. Charging external cell phones or other electronic devices
8. Operation time up to 18 hours (medium volume level)

SimplyVibe™

MODEL: V5-BT1


**BLUETOOTH® WIRELESS STEREO SPEAKER
Instruction Manual**



The Bluetooth word, mark and logo are owned by Bluetooth SIG, Inc. Any and all other trademarks and trade names are those of their respective owners.

Simply Globo Inc.
Chicago, IL
www.simplyglobo.com


C. COMPONENT IDENTIFICATION



1. Power On/Off Control
2. Battery Check / Bluetooth Pair Button
3. Power LED Indicators
4. Battery charging LED Indicator
5. 3.5mm Audio input jack
6. Micro USB charge input jack
7. Telephone call button
8. Volume +
9. Volume -
10. USB Charging out jack(to external portable devices)
11. Microphone
12. Speaker
13. Passive Woofer (located on back panel of unit)


D. PAIRING

1. Make sure the speaker is On.
2. Enable your Bluetooth device such as cell phones, tablets or other BT media, and make sure it is in searching mode.
3. Press the Pair/Battery Check button and hold for 5 seconds until the 4 LEDs flash.
4. Select "SimplyVibe V5-BT1" in the list shown in the Bluetooth device.
5. Enter "0000" if password is required.
6. When Bluetooth connection is made, the first LED will flash slowly.
7. Listen to your music or make/receive your telephone call on the speaker.



E. CHARGING

1. Make sure the speaker is fully charge before initial use.
2. Connect speaker with your PC by the supplied USB to Micro USB cable for charging.
3. Charging is workable to connect with other power adapter with USB jack at 5V 1A specifications.
4. The charging LED will illuminate in Red when charging . Charging is finished when LED turns Green.




F. TELEPHONE CALL

1. If there is an incoming call when streaming music on the speaker, the music will be muted and ring tone will be heard.
2. Take your call by pressing the talk button. Press once again when ending the call. Music will resume again automatically.
3. To make a call, simply dial your cell phone and talk to the speaker.

Note: Check the instruction manual for your cell phones, if getting any process different from the above.

G. LINE-IN

1. Connect the speaker to your audio device directly with the 3.5mm cable provided.
2. The Bluetooth wireless music will be by pass after line-in connection is made.



H. BATTERY CHECK

1. The speaker is designed with a smart battery check feature, so that user knows clearly the battery status of the battery.
2. Press the battery check button and note the battery status.
 - a/ 4x LED light up = approx. 100% full
 - b/ 3x LED light up = approx. 75%
 - c/ 2x LED light up = approx. 50%
 - d/ 1x LED light up = approx. 25% (charging is needed)

I. CHARGING OUTPUT

1. V5-BT1 supplies with charging out feature to support your portable devices with back-up power supply
2. Connect your portable device by its charging cable along with the USB jack at V5-BT1 speaker.

* V5-BT1 is designed for charging portable device with charging current lower than 1A. Charging tablets or other high power portable device is not recommended as halt up of V5-BT1 will likely happen.

J. TECHNICAL SPECIFICATIONS

Carrier Frequency	:	Bluetooth 2.1
Battery Capacity	:	3.7V 1500mA
Frequency Response	:	20Hz – 20KHz
Distortion	:	0.5%
S/N Ratio	:	65dB (typical)
Channel Separation	:	50dB (Typical)
Operation Distance	:	Up to 10 meters
Output Power	:	/ 33 feet (open area) 2 x 1.5W (Max)

NOTES: This speaker is in compliance with the specified Bluetooth version. It does not guarantee compatibility of all functions on every Bluetooth enabled device. Please check with your mobile phone's user manual for compatibility and functionality.

K. TROUBLE SHOOTING

NO SOUND

- Ensure the speaker is charged and with enough power for operation
- Ensure the speaker is ON.
- Ensure Bluetooth device is ON.
- If the volume of speaker is too low, adjust the volume to an appropriate level.
- Unable to connect with Bluetooth device, RESET the speaker by pressing and holding the Pair/Battery Check button for 12 seconds.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: Clean the speaker with soft, lint - free, dry cloth. Never use detergents or abrasive cleaners to clean.

L. FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Important: Changes or modifications to this product not authorized and could void the FCC compliance and negate your authority to operate the product.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.